

EasyUAClient Parameters Overview

Static Parameters		
EasyUAClient.AdaptableParameters	EasyUAdaptableParameters	Adaptable parameters for non-isolated client objects.
.Discovery	UADiscoveryParameters	Contains parameters that influence the behavior of the component on the discovery level.
.Host	UAHostParameters	Contains parameters that influence the behavior of the component on the host level.
.MonitoredItem	UAClientMonitoredItemParameters	Contains parameters that influence the behavior of the component on the monitored item level.
.Session	UASmartSessionParameters	Contains parameters that influence the behavior of the component on the session level.
.Subscription	UAClientSubscriptionParameters	Contains parameters that influence the behavior of the component on the subscription level.
EasyUAClient.SharedParameters	EasyUASharedParameters	Parameters that are always shared by all instances of the component.
.Engine	EasyUAEngineParameters	Contains values for determining certain OPC-UA parameters heuristically.
Object Parameters		
easyUAClient.InstanceParameters	EasyUAInstanceParameters	Contains parameters that influence the behavior of just this instance of the OPC-UA component.
.Mode	EasyUAClientMode	Specifies common parameters that influence the OPC-UA client mode of operation.
easyUAClient.Isolated	bool	Specifies that the EasyUAClient object instance works with an "isolated" connection to the OPC-UA server.
easyUAClient.IsolatedParameters	EasyUAdaptableParameters	Contains parameters that influence the behavior of the component when it is isolated.
(see above)		